Accessing the CD

Place the **LARGAN Digital** CD-ROM into the appropriate drive. The LARGAN Digital Main Menu screen will automatically appear. If the main menu screen doesn't appear, follow the directions below.

Step 1 Double-click on the **My Computer** icon on your desktop.

Step 2 Double-click on the **CD-ROM** icon.

Step 3 Double-click on the **Autorun** icon.

Step 4 The LARGAN Digital Main Menu screen will appear.

Note: You can also download the driver via the Largan website. Please go to www.largan.com for more details.

1 Install the Driver

In order for you to download pictures from the camera to your computer, you will need to install the driver.

Step 1 Click on **" Install Mega+2 Digital Camera"** on the autorun screen.

Step 2 Click **Next** on the Welcome screen.



Step 3 The files will begin to copy to your computer.

Step 4 Click **"Finish"** to end the setup.



Step 5 In order for the driver to take effect, you should click **"OK"** to restart your computer now.



Step 6 Connect the camera to the computer using the USB cable. The screen will show **Found New Hardware**.

Note: Always use the same USB port when using your digital camera.

Step 7 Select **Install the software automatically (Recommended)**. Click **Next** to continue.

Step 8 Please wait while the wizard searches.

Step 9 The installation will start to install the Mega+2 digital camera.



Step 10 Click **Finish**. The Mega+2 digital camera has been successfully installed.

Step 11 The Found New Hardware Wizard detects the camera. The screen will show **Found New Hardware**.

Note: Now the wizard will install the video side of the camera (continue to the next step).

Step 12 Select **Install the software automatically (Recommended)**. Click **Next** to continue.

Step 13 Please wait while the wizard searches.



Step 14 The installation will start to install the Mega+2 video camera.



Step 15 Click **Finish**. The Mega+2 video camera has been successfully installed.

Step 16 The screen will display **"Your new hardware is installed and ready to use"**, the Mega+2 driver is now successfully installed.



2 Downloading Photos

Step 1 Connect the camera to your computer using the USB cable.

Step 2 Click on **Start** from the Windows Task Bar.

Step 3 Click on **Programs**.

Step 4 Click on **Largan Digital Camera** program group.

Step 5 Click on the **Mega+2 Digital Camera** icon.

Step 6 The Largan thumbnail viewer will appear.

It allows you to view photos that are stored in the camera's memory. You are now ready to download your photos to the computer.

Step 7 You also can click on the button to view the enlarged image on the image browser.



To download an individual photo:

Step 8 Click on the desired photo. The photo number will turn red when selected.

Step 9 Click on the **Save** button located at the right of the thumbnail viewer.

Step 10 Type in the file name and click on **Save**.

Step 11 The photo has been stored in the computer.

Note: To download all of the photos, click on the **Select All** button. Next, click on the **Save** button. To download files in a non-consecutive order, just click on the desired photos, then click on the **Save** button.

Step 12 Click on the **Exit** button when you have finished downloading your photos.

3 Erasing Photos from the Camera

To erase all of the photos:

Step 1 Disconnect the camera from the USB cable.

Step 2 Press the **Mode/Power** button 3 times until you see the icon appear in the menu panel.

Step 3 Press and hold the **Shutter** button down for 3 seconds. Notice how the menu panel displays zero (0) photos.

Step 4 Press and hold on the **Mode/Power** button to turn the camera off.

Note: When the camera is connected to the computer by the USB cable, you can click on the button located at the thumbnail viewer.

4 Using the Video Recording Feature

Step 1 Press the **Mode/Power** button until you see the icon appears.

Step 2 Press the **Select** ▲ button until you see the icon appears.

Step 3 Press the **Shutter** button, using the optical finder to compose images.

Step 4 Press the **Shutter** button again when you complete a video file.

Note: If the video is under 16 MB, you can record several video files.

Step 5 Connect the camera to your computer via the USB cable.

Step 6 Click on the **Mega+2 Digital Camera** icon by the following. And the thumbnail viewer will now appear .

Start \ Programs\ Largan Digital Camera program group \ **Mega+2 Digital Camera**

Step 7 Left click on the image browser icon.

Step 8 The image browser will appear.

Step 9 Click on the AVI icon located below the image thumbnail.

Step 10 The image browser will appear. Press the icon to play the movie.



Step 11 If you want to stop during playback, press the icon or press the icon to pause the playback.

Step 12 Press or icon to view the other enlarged image on the image browser.



5 Taking Photos in TV Mode

To take the photo in TV mode follow the steps below.

Step 1 Make sure the batteries are properly inserted into the camera.

Step 2 Press **Mode/Power** button. The camera will beep.

Step 3 Connect the camera to your television via the TV cable.

Step 4 Press the **Mode/Power** button 4 times until the icon" NTSC " appears in the menu.

Step 5 Compose the picture and press the **Shutter** button.

6 Using the Preview Feature in TV Mode

To use the preview feature follow the steps below.

Step 1 Make sure the batteries are properly inserted into the camera.

Step 2 Press **Mode/Power** button. The camera will beep.

Step 3 Connect the camera to your television via the TV cable.

Step 4 Press the **Mode/Power** button 4 times until the icon" NTSC " appears in the menu.

Step 5 Press the **Mode/Power** button one time.

Step 6 The menu in the camera will display (001) photos.

Step 7 Press **Select** ▲ or **Select** ▼ button to move the white line box to the desired image in the multi-image replay mode via the television.

Step 8 Press the ϟ/⏻ button to enlarge the desired image. Select the other enlarged images by pressing **Select** ▲ or **Select** ▼ button.

Note: Press the **Mode/Power** button to go back to the multi-image play mode.

Step 9 In enlarged image replay, select the AVI file you wish to play using the **Select** ▲ or **Select** ▼ button. Then press the ϟ/⏻ button to play the movie. You can press the ϟ/⏻ button again to pause the movie.

Step 10 At the same time, you can also delete the image, press the **Shutter** button 2 times.

Quick Start Guide

Start Here...
Read this Quick Start Guide

❶ Install the Driver
❷ Downloading photos
❸ Erasing Photos from the Camera
❹ Using the Video Recording Feature
❺ Taking photos in TV Mode
❻ Using the Preview Feature in TV Mode

Mega+2

1-628-13-0021-02